

SHIFT KNOB (M/T)

Remove shift knob with turning counterclockwise.

CONSOLE FINISHER (A/T)

1. Insert a thin flat-bladed screwdriver wrapped with tape from behind console finisher A/T, and remove metal clip on back. Then pull up and back to disengage from front metal clip.
2. Disconnect A/C harness connector, and remove console finisher.

NOTE:

A/C controller is assembled in the console finisher (A/T). Therefore, when installing and removing be careful not to use excessive force, etc.

