

# Report

2024-06-04 22:22

## Vehicle Information

Vehicle Name : NISSAN

Year:

VIN:

Mileage : 0mile

SN: D7W-WC866TM

Diagnosis Route :

## Engine

### Live Data

NO.	Name	Value	Maximum Value	Minimum Value	Unit
1	Engine Speed	0.00	0.00	0.00	RPM
2	Mass Air Flow Sensor - Bank 1	0.35	0.38	0.31	V
3	Coolant Temperature Sensor	131.00 129.20	144.10	117.90	deg F
4	Air Fuel Ratio (A/F) Sensor 1 - Bank 1	1.52	1.67	1.37	V
5	Air Fuel Ratio (A/F) Alpha - Bank 1	100.00	110.00	90.00	%
6	Air Fuel Ratio (A/F) Alpha - Bank 2	100.00	110.00	90.00	%
7	Vehicle Speed Sensor	18.63 0.00	20.49	16.77	mph
8	Battery Voltage	12.56	13.82	11.30	V
9	B/Fuel Schedule	12.88 12.92	14.21	11.59	Msec
10	Accelerator Sensor 1	0.73	0.80	0.66	V
11	Throttle Position Sensor 1 - Bank 1	0.71	0.79	0.64	V
12	Inlet Air Temperature Sensor	131.00	144.10	117.90	deg F
13	Start Signal	Off			
14	Closed Throttle Position	On			
15	Air Conditioner Signal	Off			
16	P/N Position Switch	On			
17	Power Steering Signal	Off			
18	Load Signal	Off			
19	Injection Pulse - Bank 1	8.84	9.72	7.96	Msec
20	Ignition Timing	110.00	121.00	99.00	BTDC
21	Air Conditioner Relay	Off			
22	Fuel Pump Relay	Off			
23	Throttle Relay	On			
24	Cooling Fan	Off			
25	Air Fuel Ratio (A/F) Sensor 1 - Bank 2	1.52 1.51	1.67	1.36	V
26	Heated Oxygen Sensor 2 - Bank 1	0.28	0.31	0.25	V
27	Heated Oxygen Sensor 2 - Bank 2	0.28	0.31	0.25	V
28	Heated Oxygen Sensor 2 Monitor - Bank 1	Lean			
29	Heated Oxygen Sensor 2 Monitor - Bank 2	Lean			

30	Accelerator Sensor 2	0.71	0.78	0.64	V
31	Throttle Position Sensor 2 - Bank 1	0.70	0.77	0.63	V
32	Fuel Tank Temperature Sensor	77.00	84.70	69.30	deg F
33	Evaporation Emission System Pressure	3.86	4.25	3.47	V
34	Fuel Level Sensor	2.56	2.82	2.30	V
35	Ignition Switch	On			
36	Heater Fan Switch	Off			
37	Brake Switch	On			
38	Injection Pulse - Bank 2	8.84	9.72	7.96	Msec
39	Calculate Load Value	0.00	0.00	0.00	%
40	Mass Air Flow	0.94	1.03	0.85	G/S
41	Purge Volume Control Valve (C/V)	0.00	0.00	0.00	%
42	Inlet Valve Timing - Bank 1	0.00	0.00	0.00	degCA
43	Inlet Valve Timing - Bank 2	0.00	0.00	0.00	degCA
44	Exhaust Valve Timing - Bank 1	0.00	0.00	0.00	degCA
45	Exhaust Valve Timing - Bank 2	0.00	0.00	0.00	degCA
46	Inlet Valve Solenoid - Bank 1	0.00	0.00	0.00	%
47	Inlet Valve Solenoid - Bank 2	0.00	0.00	0.00	%
48	Variable Timing Control (VTC) Duty Exhaust - Bank 1	0.00	0.00	0.00	%
49	Variable Timing Control (VTC) Duty Exhaust - Bank 2	0.00	0.00	0.00	%
50	Ventilation Control Valve	Off			
51	Heated Oxygen Sensor 2 Heater - Bank 1	Off			
52	Heated Oxygen Sensor 2 Heater - Bank 2	Off			
53	Vehicle Speed	0.00			mph
54	Idle Air Valve Learn	Completed			
55	Travel After Malfunction Indicator Lamp (MIL)	0.00	0.00	0.00	mile
56	Engine Oil Temperature	127.40	140.14	114.66	deg F
57	Air Fuel Ratio (A/F) Sensor 1 Heater - Bank 1	0.00	0.00	0.00	%
58	Air Fuel Ratio (A/F) Sensor 1 Heater - Bank 2	0.00	0.00	0.00	%
59	Air Conditioner (AC) Pressure Sensor	1.16	1.28	1.04	V
60	Set Vehicle Speed	0.00			mph
61	Main Switch	Off			
62	Cancel Switch	Off			
63	Resume/Acceleration Switch	Off			
64	Set Switch	Off			
65	Brake Switch 1	Off			
66	Brake Switch 2	On			
67	Vehicle Speed Cut	Non			
68	Low Speed Cut	Non			
69	Automatic Transmission (AT) Overdrive (OD) Monitor	Off			

70	Automatic Transmission (AT) Overdrive (OD) Cancel	Off		
71	Cruise Lamp	Off		
72	Set Lamp	Km/H		
73	Exhaust Valve Torque Learn	Completed		
74	OPTION 1	0.00	0.00	0.00
75	OPTION 2	0.00	0.00	0.00

### Meter/M&A

#### Live Data

NO.	Name	Value	Maximum Value	Minimum Value	Unit
1	Fuel Warning Lamp	Off			
2	Buzzer	Off			
3	Malfunction Indicator Lamp (MIL)	On			
4	Air Pressure Warn Lamp	Off			
5	Seat Belt Warning Light (W/L)	On			
6	Door Warning Lamp	On			
7	High-Beam Indicator	Off			
8	Turn Indicator	Off			
9	Oil Warning Light (W/L)	On			
10	Vehicle Dynamic Control (VDC)/Traction Control System (TCS) Indicator	Off			
11	Anti-Lock Brake System (ABS) Warn Lamp	Off			
12	Slip Indicator	Off			
13	Brake Warning Lamp	Off			
14	Automatic Transmission (AT) Park Mode Switch	Off			
15	Automatic Transmission (AT) Sport Mode Switch	Off			
16	Brake Switch	On			
17	Cruise Indicator	Off			
18	Set Indicator	Off			

Remark:

\*This report is only responsible for the results of this detection: