


# TROUBLE DIAGNOSIS

## Component Parts Location

AHS0001U



- |                                       |                                   |                                       |
|---------------------------------------|-----------------------------------|---------------------------------------|
| 1. Driver air bag module              | 2. Front passenger air bag module | 3. Spiral cable                       |
| 4. Front side air bag module          | 5. Diagnosis sensor unit          | 6. Side air bag (Satellite) sensor LH |
| 7. Side air bag (Satellite) sensor RH | 8. Seat belt pre-tensioner RH     | 9. Seat belt buckle switches          |
| 10. Seat belt pre-tensioner LH        | 11. Side curtain air bag module*  | 12. Crash zone sensor                 |

\*: For Coupe

A  
B  
C  
D  
E  
F  
G  
SRS  
I  
J  
K  
L  
M