









FUEL PUMP CIRCUIT

Wiring Diagram



ABS0090Q

EC-F/PUMP-01



REFER TO THE FOLLOWING.

(E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)



TBWT0633E